

Multi Super DC inverter

Tabulky kombinovatelnosti

M2OH-14HFN8-Q(B)			M2OE-18HFN8-Q(B)			M3OA-18HFN8-Q(B)			
1 vnit. j.	2 vnit. j.		1 vnit. j.	2 vnit. j.		1 vnit. j.	2 vnit. j.	3 vnit. j.	
	9	9 + 9		9	9 + 9		9	9 + 9	9 + 9 + 9
	12	9 + 12		12	9 + 12		12	9 + 12	—
	18	—		18	12 + 12		18	9 + 18	—
							—	12 + 12	—

M3OG-21HFN8-Q(B)				M3OA-27HFN8-Q(B)					
1 vnit. j.	2 vnit. j.	3 vnit. j.		1 vnit. j.	2 vnit. j.	3 vnit. j.			
	9	9 + 9	9 + 9 + 9		9	9 + 9	12 + 12	9 + 9 + 9	9 + 12 + 12
	12	9 + 12	—		12	9 + 12	12 + 18	9 + 9 + 12	12 + 12 + 12
	18	9 + 18	—		18	9 + 18	—	9 + 12 + 12	—
	—	12 + 12	—						

M4OE-28HFN8-Q(B)					
	1 vnit. j.	2 vnit. j.		3 vnit. j.	4 vnit. j.
	9	9 + 9	12 + 18	9 + 9 + 9	9 + 9 + 9 + 9
	12	9 + 12	12 + 24	9 + 9 + 12	—
	18	9 + 18	18 + 18	9 + 9 + 18	—
	24	9 + 24	—	9 + 12 + 12	—
	—	12 + 12	—	12 + 12 + 12	—

M4O-36FN8-Q(B)							
	1 vnit. j.	2 vnit. j.		3 vnit. j.		4 vnit. j.	
	9	9 + 9	18 + 18	9 + 9 + 9	9 + 18 + 18	9 + 9 + 9 + 9	12 + 12 + 12 + 12
	12	9 + 12	—	9 + 9 + 12	12 + 12 + 12	9 + 9 + 9 + 12	12 + 12 + 12 + 18
	18	9 + 18	—	9 + 9 + 18	12 + 12 + 18	9 + 9 + 9 + 18	—
	24	9 + 24	—	9 + 9 + 24	12 + 12 + 24	9 + 9 + 12 + 12	—
	—	12 + 12	—	9 + 12 + 12	12 + 18 + 18	9 + 9 + 12 + 18	—
	—	12 + 18	—	9 + 12 + 18	—	9 + 12 + 12 + 12	—
	—	12 + 24	—	9 + 12 + 24	—	9 + 12 + 12 + 18	—

M5OE-42HFN8-Q(B)								
	1 vnit. j.	2 vnit. j.	3 vnit. j.		4 vnit. j.		5 vnit. j.	
	9	9 + 9	9 + 9 + 9	12 + 12 + 12	9 + 9 + 9 + 9	12 + 12 + 12 + 12	9 + 9 + 9 + 9 + 9	12, 12, 12, 12, 12
	12	9 + 12	9 + 9 + 12	12 + 12 + 18	9 + 9 + 9 + 12	12 + 12 + 12 + 18	9 + 9 + 9 + 9 + 12	—
	18	9 + 18	9 + 9 + 18	12 + 12 + 24	9 + 9 + 9 + 18	—	9 + 9 + 9 + 9 + 18	—
	24	9 + 24	9 + 9 + 24	12 + 18 + 18	9 + 9 + 9 + 24	—	9 + 9 + 9 + 12 + 12	—
	—	12 + 12	9 + 12 + 12	—	9 + 9 + 12 + 12	—	9 + 9 + 9 + 12 + 18	—
	—	12 + 18	9 + 12 + 18	—	9 + 9 + 12 + 18	—	9 + 9 + 12 + 12 + 12	—
	—	12 + 24	9 + 12 + 24	—	9 + 12 + 12 + 12	—	9 + 12 + 12 + 12 + 12	—
	—	18 + 18	9 + 18 + 18	—	9 + 12 + 12 + 18	—	9 + 12 + 12 + 12 + 18	—